

PARAGLAZE GLOSS COLOUR

PRODUCT DESCRIPTION

Paraglaze Gloss is a premium two pack acrylic urethane single layer topcoat developed specifically to give solid and metallic colours the durability to withstand the harsh Australian conditions.

The world-class technology offers easy application that delivers excellent coverage and a high gloss finish off the gun.

PRODUCTS

Paraglaze Gloss Colour	PM-GMIX, PM-GXXX
Paraglaze CT 4:1 Quick Dry Hardener	PH-2000
Paraglaze Hardener Low Temp	PH-4100
Paraglaze Hardener Standard	PH-4200
Paraglaze Hardener High Temp	PH-4300
Paraglaze Reducer Low Temp	PS-6100
Paraglaze Reducer Standard	PS-6200
Paraglaze Reducer High Temp	PS-6300
Paraglaze Reducer Extra High Temp	PS-6400
Paraglaze Maxiglaze Accelerator Thinner	PS-6080
PROTEC® Flex Additive	AA-5656
Paraglaze Gloss Matting Base	PT-G132
<i>Protec</i> Heavy Duty Wax & Grease Remover	AA-6822

SUBSTRATES & PREPARATION



Paraglaze Gloss can be applied over:

- Sound OEM finishes that have been degreased and sanded
- Sound, fully cured 2 pack refinish finishes that have been degreased and sanded
- Paraglaze 2 pack primers that have been degreased and sanded
- Plastics that have been prepared and coated with a *Protec* plastics primer




Substrates other than those stated above should be tested before use, to ensure that the performance of this product is suitable for its intended use.

The use of a clean tack rag is recommended to remove dust from the surface before topcoating.

REDUCER AND HARDENER SELECTION GUIDE


TEMPERATURE RANGE	PRODUCTS TO USE
Up to 20°C (<i>mainly air dry use</i>)	PH-4100 PS-6100
20°C to 30°C (<i>most common choice</i>)	PH-4200 PS-6200
30°C to 40°C (<i>also for large areas</i>)	PH-4300 PS-6300
Over 40°C (<i>also for large areas</i>)	PH-4300 PS-6400

MIXING RATIO BY VOLUME



PRODUCT	PARTS
2:1 MODE	
Paraglaze Gloss Colour	2
Paraglaze Hardener	1
Paraglaze Reducer	5 - 20% - If using PS-6080 substitute full amount
4:1 MODE	
Paraglaze Gloss Colour	4
PH-2000	1
Paraglaze Reducer	30% - If using PS-6080 use 50% Reducer + 50% PS-6080

FLEXIBILISATION




AA-5656 *Protec* Flex Additive must be used at the following ratios when applying PM-GMIX over plastics, to ensure proper flexibility of the clearcoat film:

PLASTIC TYPE	HARD PLASTICS	FLEXIBLE PLASTICS	HIGHLY FLEXIBLE PLASTICS
PRODUCT	PARTS		
Uncatalysed PM-GMIX	Not Required	5	2
AA-5656		1	1

Always add AA-5656 to PM-GMIX first and thoroughly mix → Then add hardener and reducer as per the normal 2:1 or 4:1 recommendations.


Note: Higher levels of AA-5656 will slow the drying time of PM-GMIX.

POTLIFE



2:1 MODE	4 hours at 25°C or 1 hour when using PS-6080 Accelerator Thinner
4:1 MODE	3 hours at 25°C

GLOSS ADJUSTMENT GUIDE



To allow for normal variations in the gloss level, depending on the colour, model, position of repair on vehicle etc., it is possible to mix PM-GMIX and PT-G132 in any ratio to match the required gloss for a particular repair.


The mixing ratios quoted below give the best starting point:

GLOSS EFFECT	Matt	Low Gloss	Semi-Gloss
GLOSS RANGE	0 - 10%	20.1 - 30%	45.1 - 60%
INGREDIENT	Mixing Ratio - Parts by Weight		
PM-GMIX	100	100	100
PT-G132	100	75	60

Activate and reduce the resulting mix as above.

Note: Test panels MUST be sprayed out using the intended hardener/reducer ratio and spraygun combination to check for colour and gloss level against the vehicle to be repaired.

SPRAY VISCOSITY



17 - 19 seconds (DIN 4) at 25°C.

SPRAYGUN SETTINGS (GRAVITY)




SETUP 1.3 - 1.4 mm

SPRAY PRESSURE

- HVLP / RP: 1.8 - 2.2 bar
- CONVENTIONAL: 3.0 - 3.5 bar

APPLICATION & FLASH OFF (at 25°C)



- COATS: Apply 2 - 3 medium, wet, even coats
- FLASH OFF BETWEEN COATS: 3 - 5 minutes

DRYING TIMES & TEMPERATURE



BAKE: 40 minutes at 60°C

INFRA RED (I.R.): Will vary depending upon equipment. Refer to equipment supplier



AIR DRY: Handle after 12 hours at 25°C
Polish after 24 hours at 25°C

Note: Drying times will need to be extended under cooler conditions. Seek further advice before spraying. Temperature shown is metal temperature.

TOTAL DRY FILM BUILD 40 - 60 µm with 2 - 3 coats

OVERCOAT / RECOAT



PREPARATION: STARTLINE® P500 (dry) or P800 (wet) abrasive, after bake

TIME: Recoatable with itself within 1-2 hours
If rectifying, allow 16 hours air dry at 25°C or bake first

DE-NIBBING & POLISHING

Remove dirt if required using wet *Startline* abrasive, no more than P1500 grit, then cut and polish.

EQUIPMENT CLEANING

After use, clean all equipment thoroughly with cleaning solvent or thinner.

HEALTH AND SAFETY

Refer to Safety Data Sheets (SDS) for full Health and Safety details, as well as product can labels.

Protec hardeners and activated products contain isocyanate and therefore particular safety precautions must be taken; please refer to SDS for full health and safety details.

This product is for professional use only.
The information given in this sheet is for guidance only. Any person using the product without first making further inquiries as to the suitability of the product for the intended purpose does so at his or her own risk and we can accept no liability for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of such use. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.
Drying times quoted are average times at 25°C/77°F. Film thickness, humidity and shop temperature can all affect drying times.

**PPG Industries Australia Pty Ltd, 14 McNaughton Rd
Clayton, V.I.C. 3168 Australia**

EMERGENCY RESPONSE NUMBER, Australia: 1800 883 254

**PPG Industries New Zealand Pty Ltd, 5 Vestey Dr, Mt Wellington
Auckland, New Zealand**

EMERGENCY RESPONSE NUMBER, New Zealand: 0800 000 096

Protec and the *Protec Logo* are registered trademarks of Protec Pty Ltd.
Startline is a registered trademark of PPG Industries Australia Pty Ltd.