

PP-2500

PARAGLAZE TINT & PRIME

PRODUCT DESCRIPTION

Paraglaze Tint & Prime can be used as a tintable primer surfacer or wet-on-wet primer - it can be tinted with Paraglaze Gloss (PT-G) tinters up to 20%.

Recommended for use under Paraglaze Basecoat and Paraglaze Gloss, Paraglaze Tint & Prime offers excellent surface levelling and gloss holdout.

PRODUCTS

Paraglaze Tint & Prime	PP-2500
Paraglaze Hardener Low Temp	PH-4100
Paraglaze Hardener Standard	PH-4200
Paraglaze Reducer Low Temp	PS-6100
Paraglaze Reducer Standard	PS-6200
Paraglaze Reducer High Temp	PS-6300
PROTEC® Flex Additive	AA-5656
Protec Heavy Duty Degreaser	AA-6822

SUBSTRATES & PREPARATION



Paraglaze Tint & Prime can be applied over the following substrates once they have been prepared as follows:



SUBSTRATE

PREPARATION

Sound OEM finishes and sound, fully cured 2 pack refinish finishes

STARTLINE® P240 - P320 (dry)

Small areas of bare steel

Startline P240 - P320 (dry)

New electrocoated panels

Startline P240 - P320 (dry)

GRP & Fibreglass

Startline P240 - P320 (dry)

Plastics

Protec Plas Stik Primer - where recommended in the AP-4880 / AP-4990 Technical Data Sheet

Large areas of bare steel and areas where polyester body filler will be applied should be coated first with AP-4110 Protec Epoxy Primer (faster option) or PP-3450 Paraglaze CT 2K HP Epoxy Primer - Grey or AP-4441 Protec Etch Primer.


Substrates other than those stated above should be tested before use, to ensure that the performance of this product is suitable for its intended use.

Continued over page...

CLEANING

Before and after any sanding operation, the substrate must be thoroughly degreased using AA-6822 *Protec* Heavy Duty Degreaser.

MIXING RATIO BY VOLUME



PRODUCT

PARTS

PP-2500

4

Paraglaze Hardener


1

Paraglaze Reducer

20 - 40% (use 40% for wet-on-wet mode)

If tinting: add up to 20% of Paraglaze Gloss (PT-G) tinter before adding hardener.

FLEXIBILISATION




AA-5656 *Protec* Flex Additive must be used at the following ratios when applying PP-2500 over plastics, to ensure proper flexibility of the primer film:

PLASTIC TYPE	HARD PLASTICS	FLEXIBLE PLASTICS	HIGHLY FLEXIBLE PLASTICS
PRODUCT	PARTS		
Uncatalysed PP-2500	Not Required	5	2
AA-5656		1	1

Always add AA-5656 to PP-2500 first and thoroughly mix → Then add hardener and reducer as per the normal recommendation above.


Note: Higher levels of AA-5656 will slow the drying time of PP-2500.

POTLIFE



Catalysed material is useable for up to 1 hour at 25°C.

SPRAY VISCOSITY



13 - 16 seconds (DIN 4) at 25°C.

SPRAYGUN SETTINGS (GRAVITY)




SETUP

1.6 - 1.8 mm (1.3 - 1.4 mm, with wet-on-wet application)

SPRAY PRESSURE

- HVLP / RP: 1.6 - 2.0 bar (1.6 - 1.8 bar, with wet-on-wet application)
- CONVENTIONAL: 2.0 - 3.0 bar (2.0- 2.5 bar, with wet-on-wet application)

APPLICATION & FLASH OFF (at 25°C)



PRIMER-SURFACER MODE

- COATS: Apply one even medium coat followed by one even wet coat
- FLASH OFF BETWEEN COATS: 5 minutes

WET-ON-WET MODE

- COATS: Apply one wet coat
- FLASH OFF BETWEEN COATS: 15 minutes

Must be topcoated within 45 minutes when using in wet-on-wet mode.


DRYING TIME & TEMPERATURE



AIR DRY: Overnight at 25°C

BAKE: 30 minutes at 60°C

Note: Temperature shown is metal temperature



I.R.: 10 - 12 minutes (short wave)

Will vary depending upon equipment. Refer to equipment supplier

TOTAL DRY FILM BUILD 25 - 50 µm

OVERCOAT / RECOAT



TIME: Within 72 hours

The vehicle must be kept dry and free of moisture and contaminants during this period.



PREPARATION: Startline P500 (dry) OR Startline P800 (wet)

PP-2500 may be topcoated with the following, or as advised by the *Protec* Technical Team:

- Two pack polyurethane topcoats such as Paraglaze Gloss
- Basecoats such as Paraglaze Basecoat

Refer to the relevant topcoat Technical Data Sheet for further details.

EQUIPMENT CLEANING

After use, clean all equipment thoroughly with cleaning solvent or thinner.

HEALTH AND SAFETY

Refer to Safety Data Sheets (SDS) for full Health and Safety details, as well as product can labels.

Protec hardeners and activated products contain isocyanate and therefore particular safety precautions must be taken; please refer to SDS for full health and safety details.

This product is for professional use only.
The information given in this sheet is for guidance only. Any person using the product without first making further inquiries as to the suitability of the product for the intended purpose does so at his or her own risk and we can accept no liability for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of such use. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.
Drying times quoted are average times at 25°C/77°F. Film thickness, humidity and shop temperature can all affect drying times.

**Protec Pty Ltd. 97–105 Bedford Street
Gillman, S.A. 5013 Australia**

EMERGENCY RESPONSE NUMBER, Australia: 1800 883 254

**Protec Pty Ltd. 5 Monahan Rd, Mt Wellington
Auckland, New Zealand**

EMERGENCY RESPONSE NUMBER, New Zealand: 0800 000 096

Protec and the *Protec Logo* are registered trademarks of Protec Pty Ltd.
Startline is a registered trademark of PPG Industries Australia Pty Ltd.